

Installation Instructions

1. Mark hole locations on mounting surface.
2. Drill pilot holes for screws.
3. Fasten screws but do not fully tighten until all screws are attached.
4. Caulk top edge of Drip Guard and around each screw to waterproof.

717S, 718S



**POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS, WOOD AND PLASTIC COVERED
COMPOSITE-TYPE FIRE DOORS
RATED UP TO 1-1/2 HOURS AND WOOD CORE DOORS
RATED UP TO 20M
CATEGORY J
<28X8>**

770S



**GASKETING MATERIALS FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS, WOOD AND PLASTIC COVERED
COMPOSITE-TYPE FIRE DOORS
RATED UP TO 1-1/2 HOURS
<28X8>**