

**Do not install so that the product inhibits the opening or closing of the door.**

1. Check the adjustment of the door to insure the door assembly closes and latches properly.
2. Measure for exact size.
3. Cut threshold to size required.
4. Notch around door frame if required.
5. Apply solid beads of adhesive to underside of threshold legs. When set the adhesive should spread thinly to cover base of all legs.

NOTE: Adhesive must be type designed to bond PVC, concrete, wood, metal or other material that threshold is being bonded to.

DO NOT WALK ON OR APPLY WEIGHT TO THRESHOLD FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.



POSITIVE PRESSURE TESTED GASKETING MATERIALS FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS RATED UP TO  
3 HOURS, WOOD AND PLASTIC COVERED COMPOSITE-TYPE FIRE  
DOORS RATED UP TO 1-1/2 HOURS AND WOOD CORE DOORS RATED  
UP TO 20M