

- Eng DOOR PREPARATION: 2 STEPS
- ① - FOLLOW HAGER® 4500 DOOR PREPARATION INSTRUCTIONS
 - ② - FOLLOW PRESENT SALTO DOOR PREPARATION SHEET INSTRUCTIONS FOR SALTO/HAGER® 4500 ADAPTER KIT

Use with HAGER® 4500
Exit Device only

- E MECANIZADO DE PUERTA: 2 PASOS
- ① - SIGA LAS INSTRUCCIONES DE PREPARACION DE PUERTA HAGER® 4500
 - ② - SIGA LAS PRESENTES INSTRUCCIONES DE PREPARACION DE PUERTA PARA EL KIT DE ADAPTACION SALTO/HAGER® 4500

OUTSIDE

INSIDE

Template
For KPB47

$\varnothing 9/16"$ [14mm]
6 THRU HOLES

$\varnothing 2-1/8"$ [54mm]
3/4" [20mm] DEEP

DEVICE
LEVER

HORIZONTAL CENTER LINE
SEE HAGER® 4500
INSTALLATION INSTRUCTIONS

VERTICAL CENTER LINE
SEE HAGER® 4500
INSTALLATION INSTRUCTIONS

$\varnothing 7"$ [25mm]
THRUHOLE

1-9/16" [40mm]

6-3/4" [171mm]

2-3/16" [55mm]

2-3/16" [55mm]

3-1/8" [80mm]