

# PARALLEL ARM TEMPLATE INSTRUCTIONS

5400 Series Door Closers

- Installing a Parallel Arm**
- Select hand of door and degree of door opening.
  - Fold template on the corresponding line for desired degree and hand.
  - Fold or cut upper corner illustrated on template and align template with the hinge edge of door.
  - At the "Frame Stop Line" fold toward you and attach template to door.
  - Mark, prep, and drill/tap 1/4"-20 holes for closer body and parallel arm bracket mounting screws.

