

To calculate extension rod length needed, use the formula below on style holder being used.

380F
Flush Mount: Measure distance from door to wall when held at desired opening. Subtract 3" (76mm) to obtain extension rod length needed.

380R
Recessed Mount: Measure distance from door to wall when held at desired opening. Subtract 2-3/8" (60mm) to obtain extension rod length needed.

380S
Surface Mount: Measure distance from door to wall when held at desired opening. Subtract 4-5/8" (117mm) to obtain extension rod length needed.

See example below using flush mount.

