



INSTALLATION SUPPLEMENT

1. Follow steps 1 thru 7B of the 3700 series instructions (I-LS00770)
2. For STEP 7C, install outside indicator assembly
3. For STEP 7D, install liner and tighten installation screws for the lever set and indicator assembly
4. To finish install, follow STEP 7E thru STEP 8

Use of Emergency Key

The emergency key is used to unlock the door in an emergency. It can only be inserted or removed when the lock is engaged (IN USE displayed).

- STEP 1:** Insert Key
- STEP 2:** Turn Key 90° to Retract Bolt

The door can now be opened.

NOTE: While the door is opened, the thumbturn can be manipulated to extend the bolt, remove the key, and then retract the bolt again.

