

1

2

3


4

A

B

C

D



Right Hand Door Shown

Door Widths 11"-17"

- This template is for the regular arm set up only.
- Dimensions are in inches and mm.
- This will work for any door in this range, but may limit the swing angle and closer size.
 - Adhere to the chart on page 2 of the regular arm installation instructions for specific swing angle options.
 - The 121° to 180° opening option will only work on doors as small as 14" in width.
- Drill pilot holes before using screws to secure.
- For installation instructions, adjustments, and more please refer to the regular arm installation instructions.



PROPRIETARY & CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAGER COMPANIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF HAGER COMPANIES IS PROHIBITED.

HAGER RESERVES THE RIGHT TO MAKE DESIGN CHANGES WITHOUT NOTICE. CALL HAGER ENGINEERING AT 1-800-325-9995 FOR THE LATEST REVISION DATE OF TEMPLATE.

ALL DIMENSIONS REFERENCE UNLESS TOLERANCE SPECIFIED.	DRAWN BY: BDG	12/18/2023	SERIES NO. 5300	PART NO. 5303
	ENG. APPR.:		PART DESCRIPTION: Regular Arm Mount 11"-17" Door Width Installation Template	
UNITS: INCH = AUTHORITY [] = MILLIMETER REFERENCE	MATERIAL:		DRAWING NO. S-CL00892	REVISION -
DO NOT SCALE	FINISH:		SHEET SIZE: A	SCALE: 1:2
	WEIGHT:			SHEET 1 OF 1